	TE-PUFPLUS Hi-Vol PAH Air Sample Data Form
Į.	
atic	Full Site Name: Portage Hny 12
Sample Information	Site Abbreviation PtG Deployment No. 29
Field Deployment and Recovery	Field Deployment Technician Name Scatt Keller Setup Date/Time 7/20/21/4:00 Sample Run Date 9/21/21 Flow Conditions should be STD. Flow Rate should be 225 liters/min. Once all necessary fields in Timer screen have been set, 3 things should happen: Green power light should start to blink; Timer countdown should start indicating when sampling run will commence; Status on main screen should change to "Waiting". Field Recovery Technician Name Scott Keller Recovery Date/Time 9/22/21/2:15 Qsta Avg Flow (liters/min) 2 (6 Actual Start Date/Time 9/21/21/0:00 Qsta Avg Flow (liters/min) 2 (6 Actual Stort Date/Time 9/21/21/0:00 Qsta Volume (m³) 3 (7.06 Tamb Avg (°C) 19.3 Elapsed Time (HH:MM) 2 4 ' 30 Pamb Avg (mrnHg) 7 4 4 Flags? Expected flags: Completed, Qsta Sample Status: VALID VOID (circle one) VOID Reason: Site Observations Run Day Temperatures: High 70 Low 56 Source: Weather Channel Run Day Wind/Wind Direction: NNW 14 mph Run Day Sky Cover: Mostly Cloudy Unusual Events? (fires, major storms, construction, etc.):
	Check all that apply.
ance	Weekly Checks: Monthly Checks: (after 5th sample run of the month) □ Power cords/plugs ok? □ Sampling head cleaned with Kim wipes? □ Gaskets ok? □ Pictures of site logbook taken? □ Shelter ok? □ Completed TE-PUFPLUS One-Point Flow Check Form? □ Tubing ok? □ Temperature sensors within ±2°C of transfer standard? □ Pressure sensor within ±10 mmHg of transfer standard? □ Debris removed? □ One-point flow verification within ±10% of Q _{std PUFPLUS} (0.225 min)? Maintenance Notes: